

# Chemical-Wash — Standard Operating Procedure

Chemical-Wash — Standard Operating Procedure

1. Purpose
2. Normal operating envelope
3. Idle reasons
4. Faults & corrective actions
5. Preventive maintenance schedule
6. References

## Chemical-Wash — Standard Operating Procedure

**Audience:** Maintenance Tech · Line Manager **Applies to:** Line-D, station 2, Chemical-Wash

### 1. Purpose

Chemical-Wash removes oils, residues, and abrasive dust from the Surface-Prep'd part before primer application. Solution chemistry control is critical to downstream paint adhesion.

### 2. Normal operating envelope

- Ideal cycle time: **30 s**
- Max acceptable cycle time: **38 s**
- Expected reject rate:  **$\leq 1\%$**
- Fault probability per cycle: **0.4 %**
- Input buffer capacity: **5 parts**

### 3. Idle reasons

| idle_reason | Meaning here                                                  | First check                      |
|-------------|---------------------------------------------------------------|----------------------------------|
| Starved     | Surface-Prep (station 1) is not feeding parts.                | Verify Surface-Prep state.       |
| Blocked     | Primer-Application (station 3) cannot accept the washed part. | Verify Primer-Application state. |

### 4. Faults & corrective actions

#### 4.1 Solution-Low

- **Symptoms in telemetry:** fault\_type = "Solution-Low". Wash quality drops; paint-adhesion rejects climb at Coating-Inspection.
- **Likely root cause:** wash tank level below the suction-line minimum due to evaporation, drag-out, or unscheduled drain.

- **Corrective action:**
  1. Refill the wash tank with deionized make-up water and chemistry.
  2. Verify pH and conductivity per recipe.
- **Restart criteria:** chemistry within recipe limits.

## 4.2 Pump-Fail

- **Symptoms in telemetry:** `fault_type = "Pump-Fail"`. Spray pressure drops to zero; wash quality nil.
- **Likely root cause:** pump motor trip, mechanical seal failure, or impeller wear.
- **Corrective action:**
  1. LOTO. Diagnose mechanical vs. electrical.
  2. Replace seal kit or motor as needed.
- **Restart criteria:** spray pressure within recipe.

## 4.3 Temp-Drift

- **Symptoms in telemetry:** `fault_type = "Temp-Drift"`. Bath temperature out of range affects cleaning efficacy.
- **Likely root cause:** immersion heater element failed, thermostat drift, or heat exchanger fouled.
- **Corrective action:**
  1. Verify element current draw.
  2. Replace failed element; verify thermocouple.
- **Restart criteria:** stable bath temperature  $\pm 2$  °C.

# 5. Preventive maintenance schedule

- **Daily:** check pH, conductivity, tank level.
- **Weekly:** clean spray nozzles.
- **Monthly:** chemistry change-out per recipe schedule.
- **Quarterly:** heat exchanger service.

# 6. References

- Maintenance\_Workflow\_Overview.pdf
- Line-D\_01\_Surface-Prep\_SOP.pdf
- Line-D\_03\_Primer-Application\_SOP.pdf