

Curing-Oven — Standard Operating Procedure (Line-D Bottleneck)

Curing-Oven — Standard Operating Procedure

1. Purpose
2. Normal operating envelope
3. Idle reasons
4. Faults & corrective actions
5. Preventive maintenance schedule
6. References

Curing-Oven — Standard Operating Procedure

Audience: Maintenance Tech · Line Manager · Quality Worker
Applies to: Line-D, station 5, Curing-Oven

1. Purpose

The Curing-Oven heat-cures the topcoat on every painted part. With a **90 s ideal cycle time**, this is the slowest station on the factory floor and the **bottleneck of Line-D** — any further slowdown immediately caps line throughput. Painted parts back up in the booth buffer if the oven slows or stops.

2. Normal operating envelope

- Ideal cycle time: **90 s** (line bottleneck)
- Max acceptable cycle time: **110 s**
- Expected reject rate: **≤ 2 %**
- Fault probability per cycle: **0.6 %**
- Input buffer capacity: **5 parts**

3. Idle reasons

idle_reason	Meaning here	First check
Starved	Paint-Booth (station 4) is not feeding parts.	Verify Paint-Booth state.
Blocked	Coating-Inspection (station 6) cannot accept cured parts.	Verify Coating-Inspection state.

Because this is the bottleneck, watching for **rising actual cycle time without a Fault yet raised** is the leading indicator of a brewing problem.

4. Faults & corrective actions

4.1 Thermocouple-Drift

- **Symptoms in telemetry:** fault_type = "Thermocouple-Drift". Cure profile out of spec; downstream Coating-Inspection rejects rise.
- **Likely root cause:** thermocouple junction degraded after long service.
- **Corrective action:**
 1. Verify thermocouple against a master probe.
 2. Replace the thermocouple; re-validate cure profile.
- **Restart criteria:** profile within ± 5 °C across the zones.

4.2 Door-Seal-Worn

- **Symptoms in telemetry:** fault_type = "Door-Seal-Worn". Heat loss; cycle time grows toward 110 s as the oven struggles to hold setpoint.
- **Likely root cause:** door gasket compressed or torn.
- **Corrective action:**
 1. LOTO. Replace the door gasket.
 2. Verify door closing pressure.
- **Restart criteria:** stable setpoint at rated cycle.

4.3 Element-Burnout

- **Symptoms in telemetry:** fault_type = "Element-Burnout". One or more zones fall short of setpoint; oven trips on under-temperature.
- **Likely root cause:** heating element failed open.
- **Corrective action:**
 1. LOTO. Diagnose the failed zone (resistance check).
 2. Replace the element.
 3. Validate the cure profile against the recipe.
- **Restart criteria:** zone temperatures balanced; profile within ± 5 °C.

5. Preventive maintenance schedule

- **Daily:** record cure profile from the trend chart.
- **Weekly:** inspect door seal; clean conveyor.
- **Monthly:** thermocouple verification against master.
- **Quarterly:** element resistance check; bake out residue.

6. References

- Maintenance_Workflow_Overview.pdf
- Safety_Lockout_Tagout_Procedure.pdf
- OEE_Targets_and_Escalation.pdf
- Line-D_04_Paint-Booth_SOP.pdf
- Line-D_06_Coating-Inspection_SOP.pdf