

Through-Hole-Insert — Standard Operating Procedure

Through-Hole-Insert — Standard Operating Procedure

- 1. Purpose
- 2. Normal operating envelope
- 3. Idle reasons
- 4. Faults & corrective actions
- 5. Preventive maintenance schedule
- 6. References

Through-Hole-Insert — Standard Operating Procedure

Audience: Maintenance Tech · Line Manager **Applies to:** Line-E, station 5, Through-Hole-Insert

1. Purpose

Through-Hole-Insert installs through-hole connectors and taller components (connectors, electrolytic capacitors) that cannot survive reflow. These parts will be wave-soldered at station 6.

2. Normal operating envelope

- Ideal cycle time: **20 s**
- Max acceptable cycle time: **26 s**
- Expected reject rate: **≤ 2 %**
- Fault probability per cycle: **0.5 %**
- Input buffer capacity: **5 parts**

3. Idle reasons

idle_reason	Meaning here	First check
Starved	AOI-Inspection (station 4) is not feeding boards.	Verify AOI-Inspection state.
Blocked	Wave-Solder (station 6) buffer full.	Verify Wave-Solder state.

4. Faults & corrective actions

4.1 Lead-Bend

- **Symptoms in telemetry:** fault_type = "Lead-Bend". Insertion fails; alarm raised on the affected channel.
- **Likely root cause:** lead-forming tooling worn; component lot out of spec.
- **Corrective action:**
 - 1. LOTO. Replace forming dies.

2. Verify component lead spacing matches the recipe.
- **Restart criteria:** five clean insertions on the offending channel.

4.2 Insertion-Miss

- **Symptoms in telemetry:** `fault_type = "Insertion-Miss"`.
Component not detected after insert; downstream Functional-Test will reject.
- **Likely root cause:** insertion head off-position or magazine empty.
- **Corrective action:**
 1. Re-teach insertion head position.
 2. Reload magazine.
- **Restart criteria:** detection on 10 consecutive cycles.

4.3 Clinch-Fail

- **Symptoms in telemetry:** `fault_type = "Clinch-Fail"`. Component inserted but not retained.
- **Likely root cause:** clinch tooling worn; clinch pressure low.
- **Corrective action:**
 1. LOTO. Inspect clinch die; replace if worn.
 2. Verify clinch pressure.
- **Restart criteria:** clinch test pulls within spec.

5. Preventive maintenance schedule

- **Daily:** verify magazines; check tooling.
- **Weekly:** inspect insertion head; clean.
- **Monthly:** clinch die service.
- **Quarterly:** head accuracy verification.

6. References

- Maintenance_Workflow_Overview.pdf
- Line-E_04_AOI-Inspection_SOP.pdf
- Line-E_06_Wave-Solder_Troubleshooting.pdf